

CAMPOMATIC

J25

vitaSqueeze

CITRUS JUICER



Made in China



INSTRUCTION MANUAL

Caution: Read and follow all safety and operating instruction before first use of this product.


Campomatic S.R.L. Via Configliachi 5/B . 35031, Abano Terme (Padova), ITALIA

WWW.CAMPOMATIC.COM

INSTRUCTION MANUAL

Structure Illustration

- | | | |
|--------------|--------------|---------------|
| A. Cup cover | B. Extractor | C. Fix Filter |
| D. Cup | E. Axis | F. Body |



BEFORE FIRST USE

Read and follow all the instructions in this “Use And Care” even if you feel you are familiar with the product, and find a place to keep it handy for future reference.

Your attention is drawn particularly to the sections concerning “IMPORTANT SAFEGUARDS” statements.

For your convenience record the complete model number (located on the product identification plate) and the date you received the product, together

with your purchase receipt and attach to the warranty and service information. Retain in the event that warranty service is required.

NOTE: The rating of this product (as marked on the product identification plate) is based on specific loading tests. Normal use or the use of other recommended attachments may draw significantly less power.

IMPORTANT SAFEGUARDS

When using any electrically powered product, basic safety precautions should always be followed, including the following:

PLEASE READ ALL INSTRUCTIONS CAREFULLY BEFORE USING THE PRODUCT.

WARNING - to reduce the risk of fire, electrical shock or injury to persons or property:

- Always operate the product from a power source of the same voltage, frequency and rating as indicated on the product identification plate.
- Close supervision is necessary when the product is used by or near children or invalids. Do not allow children to use it as a toy.
- Do not operate any product with a damaged cord or plug, or after the product malfunctions, or is dropped or appears damaged in any way. Return the complete product to the place of purchase for inspection, repair or replacement.
- Do not twist, kink or wrap the power cord around the appliance, as this may cause the insulation to weaken and split, particularly where it enters the unit.

- To reduce the risk of electric shock, do not immerse or expose the product or flexible cord to rain, moisture or any liquid other than those necessary for correct operation of the product.
- This product should not be used in the immediate vicinity of water, such as bathtub, washbowls, swimming pool etc. where the likelihood of immersion or splashing could occur.
- Never install the unit where it could be subject to:
 - * Heat sources such as radiators, heat registers, stoves or other products that produce heat.
 - * Direct sunlight
 - * Excessive dust
 - * Mechanical vibration or shock
 - * Lack of ventilation, such as bookcase or cabinet
 - * Uneven surface.
- Switch off and unplug from outlet when not in use, before assembling or disassembling parts and before cleaning. Remove by grasping the plug - do not pull on the cord.
- Do not use the appliance for other than its intended use.
- The use of attachments or accessories not recommended or sold by the product distributor may cause personal or property hazards or injuries.

Using Method

- Put out the power wire from the bottom fixed pot, and make power be on, put off the lid, then the machine is on waiting
- Separate the cleaned fruits from the middle and put them on the top of turning blade, press the fruit heavily with hands and make the turning blade turn.
- One hand take the handle of juice cup, the other fix the machinery when put the juice into the cup. Turn the juice cup right to 30 degree and put it up to make the body separated, put the juice into cup. Continue working,

must do it according to the contrary above steps

- One hand fix the juice cup, the other one handle the filter firmly, make it to be separated from juice cup completely and turn the filter to make the leaving into rubbish tube when you use this machinery; continue working, must put the filter on the juice cup.
- This appliance have two extracted head ,if you extracted big fruit can use extracted cover
- Do not put the whole or parts of body into water
- If the supply cord is damaged, must be replaced by the manufacture or its service agent or a similarly qualified person in order to order to avoid a hazard.

Clean and care

- when you cleaning ,please pull the cord first, take filter and separate the move filter ,revolve the cup at right direction ,pull the transmit axes and cleaning one by one
- Install step is reverse unpick and wash
- Covered the cup cover and store in ark after cleaning

Technology Parameter

Voltage	:	230 V~
Power	:	GTM-8109 25W
Frequency	:	50 Hz
Capacity	:	1.2L